

## **NOTES:**

- 1. BOTH RISERS SHALL BE BRASS OR TYPE K COPPER TUBING OR BRASS (HARD DRAWN) WITH COPPER/BRASS THREADED FITTINGS AND ADAPTERS.
- 2. PROVIDE ADDITIONAL SUPPORT AS NECESSARY TO SECURELY SUPPORT BACKFLOW PREVENTION ASSEMBLY.

